


# Create Part

If your part is not available when searching Digi-Key, go to **My Created Parts** on the left side and use **Create Part** to create a symbol and footprint for the part.



Enter the Manufacturer, Manufacturer Part Number and Description (optional). Each allows 254 characters.

Select the Part Classification. Many of these have sub-classifications you can select.

A screenshot of the "New Part" form on the PARTQUEST website. The form has a dark blue header with the text "New Part" and "Create a new part record". Below the header are three text input fields: "Manufacturer", "Manufacturer Part Number", and "Description". Below these fields is a section titled "Select Classification for Symbol to Part/Package Mapping:" with a "Done" button to its right. A dropdown menu is open, showing a list of classifications under "Electrical": Amplifier, Audio, Battery, Capacitor, Circuit-Protection, Data-Converter, Diode, Filter, FrequencySource, Driver, IC, Inductor, Memory, and Optoelectronic. A vertical scrollbar is visible on the right side of the dropdown menu.

Select **Done**.

The part is displayed under **My Created Parts**.

Select the **More** button to Choose Symbol & Footprint.

**Download** the part when completed.

A video is available from the Create Part page. To start the video, select the arrow next to Create Part.

LL CATEGORIES ▾

Search

Create Part

